





historic overview		2
round 800 B.C.	the general use of iron	
16th-19th century	wrought iron / cast iron (in Europe)	
round 1870 A.D.	the first production of modern steel	
late 19th century	multi-storey iron structure buildings	
early 20th century	the application of tower and mobile cranes in construc	tion
Vidovszky – BUTE/BME-Faculty of A	rchitecture – Department of Construction Technology and Management 9/11/2	2012


















4


	ID	Figure (drawing)	Geometry (mm)	Weight (kg)	Amount
1.	P-001a		4000x500x300	300	2
2.	P-001b		5000x500x300	350	2
3.	G-001		6000x500x300	420	3









































equipments		26
cranes: - moblie crane - tower crane		
lifting tools: - spreader beams - wire rope slings	7500 kg 7 7 7	
rigging tools: - lifting tounge - eye bolt - shakles - clips - hooks - clamps	¢ ° Ω Ω	3
Vidovszky – BUTE/BME-Faculty of Archite	cture – Department of Construction Technology	r and Management 9/11/2012



